



BEFORE INSTALLING LOCK, PLACE APL-N ONTO APL LOCK. MAKE SURE THAT THE CORNER CHAMFER IS FACING AWAY WHEN THREADED ONTO LOCK. THE CORNER CHAMFER DOES NOT INDICATE ANY KIND OF ORIENTATION. WHEN APL-N IS FULLY THREADED AND SEATED ONTO THE APL MAKE A SCRIBBLE LINE ON THE APL-N TO INDICATE WHERE THE HANDLE WILL BE PLACED WHEN FULLY ASSEMBLED.