

# Sizing & Measuring

## Coolflex Arm Sizing Chart (A-C)

	Small	Medium	Large	X large
C	23-32cm	28-37cm	33-43cm	39-49cm
B1	22-30cm	26-34cm	30-39cm	35-44cm
B	20-27cm	24-31cm	28-35cm	32-39cm
A	14-19cm	15-20cm	16-21cm	18-23cm

### Right

Short	2101-ARS-R	2102-ARS-R	2103-ARS-R	2104-ARS-R
Regular	2101-ARR-R	2102-ARR-R	2103-ARR-R	2104-ARR-R
Long	2101-ARL-R	2102-ARL-R	2103-ARL-R	2104-ARL-R

### Left

Short	2101-ARS-L	2102-ARS-L	2103-ARS-L	2104-ARS-L
Regular	2101-ARR-L	2102-ARR-L	2103-ARR-L	2104-ARR-L
Long	2101-ARL-L	2102-ARL-L	2103-ARL-L	2104-ARL-L

## Circumference

Left Right


C \_\_\_\_\_

B1 \_\_\_\_\_

D \_\_\_\_\_

B \_\_\_\_\_

A \_\_\_\_\_



### D Length

Short: 38-42.9cm

Regular: 43-47.9cm

Long: 48-53cm

Measure length along dorsal aspect