


Fitting Instructions: Measure around the smallest part of the ankle, and around the widest flare of the calf. Then measure the length of your leg from the heel at the floor to the bend in the knee.

Sizes	circumference		
	ankle	calf	length to knee
Small	7"-8 ¹ / ₄ " (18-21 cm)	11"-14" (28-35.5 cm)	 <p>Regular: greater than 15" (38 cm) Short: 15" (38 cm) or less</p>
Medium	8 ³ / ₈ "-9 ⁵ / ₈ " (21.3-24.4 cm)	13 ¹ / ₂ "-16" (34.3-40.6 cm)	
Large	9 ³ / ₄ "-11" (24.7-28 cm)	15 ¹ / ₂ "-18" (39.4-45.7 cm)	
X-Large	11 ¹ / ₈ "-12 ³ / ₈ " (28.2-31.4 cm)	17 ¹ / ₂ "-20" (44.5-50.8 cm)	
2X-Large	12 ¹ / ₂ "-13 ³ / ₄ " (31.7-35 cm)	19 ¹ / ₂ "-22" (49.5-56 cm)	up to 18" (45.7 cm)
3X-Large	12 ¹ / ₂ "-13 ³ / ₄ " (31.7-35 cm)	21 ¹ / ₂ "-24" (54.6-61 cm)	up to 18" (45.7 cm)

Size guide is for reference only and is not definitive. Please see a professionally trained fitter for size and fit related questions.